



# Installation & Operation Manual

## All-in-One Heat Pump Water Heater

Model: APAIO200  
APAIO270



App No NSW29118



IMK32348  
AS/NZS 2712



WaterMark

WM-032348  
AS 3498



## Table of Contents

|                           |    |
|---------------------------|----|
| 1. Safety Precautions     | 1  |
| 2. Parts and Components   | 5  |
| 3. General Information    | 8  |
| 4. Installation           | 10 |
| 5. Plumbing Connections   | 14 |
| 6. Electrical Connections | 18 |
| 7. Controller             | 20 |
| 8. Commissioning          | 29 |
| 9. Maintenance            | 30 |
| 10. Warranty              | 32 |

# 1. Safety Precautions

**Before attempting to install this unit please ensure you have read the safety precautions and fully understand them. This product must only be installed by a qualified professional in the plumbing, mechanical and/or electrical industry.**

## Warning



**1.1.** This appliance must be installed, commissioned, and serviced by an authorised person in accordance with all applicable national/local rules and regulations which include:

- a) The Plumbing Code of Australia (PCA)
- b) AS/NZS 3500.4 – Plumbing and drainage Heated water services
- c) AS/NZS 3000 – Electrical installation
- d) AS/NZS 2712.2007 – Solar and Heat Pump Water Heaters: Design and Construction
- e) AS/NZS AS 3498—2009 – Water heaters and hot-water storage tanks
- f) The power cord chosen must be compliant with AS/NZS 3191 and the nominal cross-sectional area should be 1.5 mm<sup>2</sup> or more and should handle at least 15A (2 core and earth)

- 1.2.** Warning: for continued safety of this appliance it must be installed, operated and maintained in accordance with the manufacturer's instructions
- 1.3.** Warning: This Appliance may deliver water at high temperature refer to the Plumbing Code of Australia (PCA), local requirements and installation instructions to determine if additional delivery temperature control is required.
- 1.4.** Household electrics must have a reliable earth connection.
- 1.5.** This product must be protected with a residual current device of adequate rating.
- 1.6.** Do not interfere with any permanent instruction, labels or warning plate attached to the external cover of this heat pump.
- 1.7.** Always comply with local wiring regulations.
- 1.8.** Maintenance and repair work must only be undertaken by trained and qualified personnel.
- 1.9.** The electrical connection to this product must be via a 15A RCD/MCB or RCBO with a test button function.
- 1.10.** The final electrical connection must be via a double pole isolating switch located close to the unit. The isolating switch must never be covered up.
- 1.11.** A duo valve must be installed on the cold water supply pipe for maintenance purposes.
- 1.12.** This appliance should never be used by children.
- 1.13.** If the power supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified personnel in order to avoid a hazard.
- 1.14.** The heat pump shall be installed outdoors only.

**1.15.** If the hot water system is not used for two weeks or more, a quantity of highly flammable hydrogen gas may accumulate in the water heater. To dissipate this gas safely, it is recommended that a hot tap be turned on for several minutes or until discharge of gas ceases. Use a sink, basin or bath outlet only. Appliances such as a dishwasher, washing machine or similar are not suitable. During this procedure, there must be no smoking, open flame, or any electrical appliance operating nearby. If hydrogen is discharged through the tap, it will probably make an unusual sound as it escapes – this is normal.


### R290 Warning



RISK OF FIRE

- This appliance uses R290 (propane) refrigerant, which is a flammable gas and must be serviced by an authorised person.
- **WARNING** Risk of fire/flammable material. If the refrigerant is leaking, switch off the unit at the mains and contact the service agent.
- DO NOT store chemicals or flammable materials near this appliance.
- NEVER use a flammable spray such as hair spray, paint, etc near this unit as this may cause a fire.
- Avoid risk of injury from contact with refrigerant if you notice a leak.
- If you suspect the refrigerant is leaking then:
  - Do not smoke.
  - Do not operate electrical equipment.
  - Isolate the device.
- End of life recycling: the refrigerant must not enter the atmosphere. Only have the refrigerant removed by qualified professional.
- The heat pump is designed for external installation only.


## 2. Components & Features



All in one Heat Pump Hot Water system including enamelled steel tank, & high efficiency micro channel heat exchanger. Touch Screen controller provides the user with easy access to the timer function and parameters to ensure the full flexibility of the heat pump is utilised.

### Refrigeration Circuit


#### SYSTEM SCHEMATIC



## NOTE:

All the pictures in this manual are for illustration purposes only. Please refer to local wiring and plumbing regulations. If in doubt of anything in this manual, contact your local service agent.

### Products External Dimension



| Model    | Size(mm) |      |     |      |     |      |
|----------|----------|------|-----|------|-----|------|
|          | A        | B    | C   | D    | E   | F    |
| APAIO200 | 626      | 1565 | 130 | 802  | 136 | 838  |
| APAIO270 | 626      | 1880 | 130 | 1029 | 136 | 1066 |



## 3. General Information

### 3.1 Specifications

| Model No.   | APAIO200                      | APAIO270                      |
|---|-------------------------------|-------------------------------|
| Heating Capacity at Air 20°C /15°C, Water Temperature from 15°C to 55°C |                               |                               |
| Heating Capacity(kW)  | 2.78                          | 2.78                          |
| Power Input(kW)   | 1.2                           | 1.2                           |
| COP   | 4.15                          | 4.15                          |
| Power Supply  | 220V~240V/50Hz                | 220V~240V/50Hz                |
| Heat Pump Max Power Input (W)   | 3000                          | 3000                          |
| Heat Pump Max Current (A)   | 5.3                           | 5.3                           |
| Electric Heater (W)   | 1800                          | 1800                          |
| Electric Heater Current (A)   | 7.5                           | 7.5                           |
| Refrigerant   | R290/400g                     | R290/400g                     |
| Net Dimension (mm)  | Φ626×1565                     | Φ626×1880                     |
| Package Dimension (mm)  | 700×700×1667<br>(with pallet) | 700×700×1982<br>(with pallet) |
| Net Weight (Kg)   | 104                           | 118                           |
| Gross Weight (Kg)   | 115                           | 130                           |
| Noise (dB)  | 43                            | 43                            |
| Water tank volume (L)   | 200                           | 270                           |
| Working temperature range (°C)  | -7~43                         | -7~43                         |


## 4. Installation

### 4.1. Choose a suitable location

- a. Unit must be installed outdoors only
- b. The placement must have enough space for installation and maintenance
- c. Fan inlet and outlet must have no obstruction and keep strong wind off
- d. The support surface must be flat (ie horizontal) and be able to support the heat pumps' weight. A base designed to minimise noise and vibration is ideal
- e. The noise and exhausting air don't create nuisance to neighbors' normal life
- f. The location has free ventilation
- g. If the product is installed in a location where there is a possibility of frost, then all precautions must be taken to ensure all pipework is sufficiently insulated.

### 4.2. Transporting the product.

- a. This heat pump is heavy and requires at least two people to lift it with the assistance of lifting equipment.
- b. It is always recommended to lift the product with all its packaging in place.
- c. Do not move the heat pump at the angle more than 45° (diagram below)



- d. Care and consideration should be taken into account when moving the unit as any marks caused by inappropriate handling are not deemed as defects and are not covered under warranty.


### 4.3. The Installation of Heat Pump

#### a. Base

- The unit should be installed on a concrete plinth or stable structure capable of sustaining weights in excess of 400kg. The supporting structure must not shift over time (due to water drainage etc.). A concrete base of at least 50mm depth, and a minimum dimension of 600 x 600mm is required
- Please ensure that all four feet are supported by the base being used otherwise warranties may be voided.
- Proper drainage should be observed for any overflow in accordance with AS/NZS 3500.4
- After installation the unit must be completely vertical and level as to ensure that condensate can be properly drained. If the system is installed at a level with a tilt of more than 3 degrees, warranties may be voided.
- If property damage is likely to occur due to water leakage, a safe tray (overflow tray) must be installed.


b. Air Flow

- This unit is designed for external operation only and requires a free flow of air to operate efficiently.
- Avoid installation in areas where falling debris such as leaves is prevalent as this may result in air vents being blocked or the unit being damaged.
- Avoid placing the system in locations with multiple walls or structures.
- Always maintain optimum clearances from all structures.
- All clearances shown in the below diagram must be adhered to - 300mm vertically to any fixtures/eaves, 200mm to the air intake (left of the unit when facing the controller) & 600mm to the air outlet on the opposite side. There must be a minimum of 50mm clearance from the back of the unit to the wall. Failure to adhere to all requirements will void the manufacturer's warranty and will cause the heat pump to not operate correctly or efficiently.



- The unit should be installed so that the control interface is accessible to users and that there is clear access to the electrical panel at the back of the system.

## 5. Plumbing Connections



- 1 Cold Water Inlet
- 2 Hot Water Outlet
- 3 Condensate Drain
- 4 PTR Valve 850kPa
- 5 Tempering Valve
- 6 Expansion Valve 700kPa (if required)
- 7 Pressure Limiting Valve 500kPa
- 8 Isolation Valves

### 5.1. Plumbing Connection Diagram

The plumbing of system is shown above.

- The water inlet/outlet port connections are G 3/4"
- All pipework must be sufficiently insulated with a minimum 13 mm closed cell insulation that is UV rated.

- The process of heat extraction from the atmosphere through evaporator coils results in the production of water in the form of condensation. To collect this water by-product a condensate tray is located on top of the water storage tank. Overflow from this tray runs out through the condensate drain. The systems' condensate drain is connected by a 1/2-inch copper elbow. Drain the condensate from the elbow to the nearest storm water via suitable piping. If not drained properly, the condensate line may become blocked as well produce algae and moss growth.
- The condensate line should be free of kinks and as the water is gravity fed, this should be installed vertical or with fall to ensure the free flow of water. Connecting any other pipe directly to the condensate line without an air gap will void warranties.
- Ensure the drain is clear of any air locks.
- The minimum cold-water pressure must be 200 kPa
- Pressure and Temperature Relief Valve (PTR valve)  
A PTR valve rated to 850kPa and 99°C is supplied with the system, and is to be fitted to the tank. It is a requirement that the lever on pressure & temperature relief valve (PTR) be operated once every 6 months to ensure reliable operation. It is important to raise and lower the lever gently and be careful as the water released will be hot.

**DANGER:** Failure to operate the relief valve every 6 months to ensure correct operation may result in the heat pump exploding. Continuous leakage of water from the valve may indicate a problem with the valve, or the water heater itself. Also ensure that the PTR valve and discharge point is installed in line with local plumbing regulations. Ensure PTR line is not discharged where it can cause damage or be a nuisance.

- Pressure Limiting Valve

A pressure limiting valve rated to 500kPa must be installed on the cold inlet into the tank in accordance with AS 3500.

- Tempering valve

To reduce the risk of scalding injury a tempering valve must be fitted to the hot water supply pipe work. This valve should be checked at regular intervals to ensure its operation and settings remain correct.

WARNING: SCALDING OCCURS AT 50°C. THIS APPLIANCE IS CAPABLE OF PRODUCING HOT WATER AT WELL ABOVE 50 °C. A TEMPERING VALVE MUST BE INSTALLED AS PER YOUR LOCAL GOVERNMENT AND REGULATORY REQUIREMENTS.

- Expansion control valve

The local requirements must be checked with the installer to see if this is required as part of the installation. This should be rated no more than 700 kPa.

- Non return isolation valve

It is highly recommended that this is installed to allow the hot water system to be isolated from the rest of the homes water supply, making servicing, draining and replacing the unit easy.

## **Filling and commissioning the Hot Water System**

After installation of all plumbing fittings you can fill the system. Turn on the cold water supply to the tank and open a hot water tap inside the house. Once all of the air is bled out of the hot water tap, shut this off. Open the PTR valve on the heat pump just to make sure all air is released from the tank.

**Always ensure the tank is completely full before turning on the electrical supply. Operating the unit when the tank is empty can result in damages to the electric element.**



## 6. Electrical Connections

**6.1.** The electrical connections must be completed by a qualified and trained professional and in accordance with the local and national regulations AS3000.

- This product must be wired on a dedicated circuit protected by a 15A circuit breaker
- The circuit must be connected to a reliable earth electrode connected to the unit
- The testing of the circuit and final connections are the responsibility of the trained installer


### 6.2. Power Specification

| Model \ Item         | Power supply | Cable Size (mm <sup>2</sup> ) |              | Protection Device RCBO Type (B) |      | Earth Leakage |
|----------------------|--------------|-------------------------------|--------------|---------------------------------|------|---------------|
|                      |              | L&N Conductors                | PE Conductor | Rating (A)                      | TYPE |               |
| APAIO200<br>APAIO270 | 220V/50Hz    | Φ 2.5mm                       | Φ 2.5mm      | 15                              | B    | 30mA          |

**Note:** Final connection is via a 15A isolating switch in close proximity to the heat pump

- The unit is not supplied with a 3-pin plug.
- Instead of using a 3-pin plug, hard wiring of system to a 15A isolator switch is highly recommended.
- Before any work can commence ensure that the heater is isolated from the power supply at the switchboard.
- If a power cable is damaged, it shall be replaced by a qualified professional to avoid risks

### 6.3. Wiring diagram



# 7. Controller

## 7.1. General Overview


### a. Operating conditions:

- Voltage: 220V~±10%, 50Hz±1Hz.
- Ambient temperature: -7~+43°C
- Storage temperature: -20~+70°C
- Relative humidity: 0~95%RH
- Temperature accuracy: ±1°C









### b. Main features














- Touchscreen
- Displays the current water temperature & set point temperature as standard, but can also query coil, ambient, exhaust temperatures etc
- Power cut memory function (clock still works for a limited time in the event of a power cut)
- Timer function on/off.
- Automatic defrosting.
- Error code display (if in fault) and ability to query historical errors
- Anti-freezing function
- PV function available
















## 7.2. Controller interface display and instruction of icons





| Name       | Symbol | Function  |
|------------|--------|---|
| On/off key |        | <ol style="list-style-type: none"> <li>1. On/off key (hold for 1 second)</li> <li>2. Return key</li> <li>3. Escape key</li> <li>4. Unlock key (hold for 5 seconds)</li> </ol>   |
| Clock key  |        | <ol style="list-style-type: none"> <li>1. Setting the clock, press this key to enter the clock setting mode. Press once to switch between the hour and minute selection</li> <li>2. Setting the timer (press the key and hold for 3s)</li> <li>3. When in the timer setting mode, pressing &amp; holding this key for 3s will cancel the current timer setting</li> </ol> |
| Mode key   |        | <ol style="list-style-type: none"> <li>1. Press the key to change operation mode</li> </ol>   |
| Up key     |        | <ol style="list-style-type: none"> <li>1. Press this key to change the temperature setting from main screen, or parameter value/selection value</li> <li>2. Press the key and hold for 3s to query the system status/ parameter</li> <li>3. Page up</li> </ol>  |

|                 |   |  |
|-----------------|---|--|
| Down key        |    | <ol style="list-style-type: none"> <li>1. Press this key to change the temperature setting from main screen, or parameter value/selection value</li> <li>2. Press the key and hold for 3s to query the system status/ parameter</li> <li>3. Page down</li> </ol> |
| Combination key |    | Press and hold the two keys for 5s, enter into manual intelligent distribution network connection by manual  |
|                 |    | Press and hold the two keys for 5s, enter into manual AP distribution network connection   |
|                 |    | When the heat pump is running, press these and hold these two keys for 3s to turn ON/OFF boost mode (turns ON/OFF heating element)   |
|                 |   | When the heat pump is running, press and hold these two keys for 5s to start/stop defrost mode   |
|                 |  | Press and hold these two keys for 3s to enter Ventilation mode (on high speed). Press again to run in low speed, press again to exit Ventilation mode  |
|                 |  | Press and hold these 3 keys for 5 seconds to turn ON/OFF sterilization mode  |
|                 |  | Power on within 5 minutes and don't turn on the heat pump, press the four keys and hold for 5s, restore the factory setting  |

| Symbol  | Status       | Meaning   |
|---|--------------|---|
|    | Light up     | In heating mode (if not illuminated, heat pump is off or NOT in heating mode) |
|    | Light up     | Heating element ON  |
|    | Flash for 1s | Running in Boost mode   |
|    | Flash for 2s | Running in sterilization mode   |
|    | Flash        | Searching for WIFI connection   |
|  | Light up     | WIFI connection successful  |
|  | Light up     | Water temperature   |
|  | Light up     | Water set point temperature   |
|  | Light up     | Degree Centigrade   |
|  | Light up     | N/A for this model  |
|  | Light up     | N/A for this model  |
|  | Light up     | N/A for this model  |
|  | Flash        | Heat pump OFF and in refrigerant recovery mode                                |

|   |              |                                  |
|---|--------------|----------------------------------|
|    | Light up     | Defrost mode                     |
|    | Light up     | Maintenance mode                 |
|    | Light up     | Heat pump has an error           |
|    | Light up     | Screen locked                    |
|    | Light up     | Compressor running               |
|    | Light up     | High fan speed                   |
|    | Light up     | Low fan speed                    |
|  | Flash for 1s | Ventilation mode: high fan speed |
|  | Flash for 2s | Ventilation mode: low fan speed  |
|  | Display      | Error code display               |
|  | Light up     | Timer ON                         |
|  | Display      | In timing ON period              |
|  | Flash        | Setting timing ON                |
|  | Display      | In timing OFF period             |
|  | Flash        | Setting timing OFF               |

|   |                          |                    |
|---|--------------------------|--------------------|
|  | Light up /<br>Not bright | Timer number 1/2/3 |
|  | Display                  | Week               |

### 7.3. Lock and unlock:

When the controller is in the normal display mode and there is no button operation for more than 60 seconds it will automatically lock. Press the on/off key for 5 seconds to unlock - a beep will confirm.

### 7.4. Turn ON/OFF the Heat Pump:

When the controller is in the normal display mode, press on/off key for more than 1 second to switch the controller to the power ON or OFF mode.

### 7.5. Water Temperature Set

With the controller unlocked and in the normal display mode, press the up or down key to increase or decrease the water temperature setting value. In accordance with Australian Government guidelines the heat pump is programmed to revert back to a temperature setpoint of 55°C every 24 hours to enhance efficiency. As such, a setpoint of 55°C is advised

### 7.6. Operation mode selection:

With the controller in the main interface display, press the Mode key to show the current operating mode. Pressing the Mode key again will switch between the different operating modes. This function will time out after 8 seconds, and revert back to the normal display. The system default mode is Standard (STAN), which will be the selected mode on start up.



### Operation Modes List:

| No. | Mode  | Symbol |
|-----|---|--------|
| 01  | Standard Mode - this mode uses the heat pump only to achieve desired temperatures   | STAN   |
| 02  | Boost Mode - this mode uses both the heat pump & the electric element to achieve the desired temperatures quicker. The heat pump will stay in Boost mode until it is manually switched back to Standard | HYBL   |
| 03  | Electric Mode - this mode uses the electric element ONLY, not the heat pump. This mode should be used ONLY in the event of a failure within the heat pump part of the unit.                             | ELE    |

### 7.7. Clock settings:

With the controller in the main interface display, press the Clock key to enter the time setting interface. Pressing the clock key again will select the Hour - use the up or down keys to select. Press the clock key again to change selection to minutes and repeat. Push the clock key again to confirm the time and return to the main display within the time setting interface, the operation will time out if no button is pressed in 60 seconds

### 7.8. Setting the Timer:


The timer allows 3 separate on/off periods per day (per 24 hour period)

While in the controller main interface display, press and hold the Clock key for 3 seconds to enable/disable and set the timer functions.

The setting process will start with Timer 1 flashing. Press the clock key to highlight the hour field, then use the up and down keys to enter your desired start time (hour) for time period



1. Once selected, pressing the clock key will move to the minute field - again, select your desired start time (minutes) for time period 1. Once the start time is set, press the clock key to enter the end time for time period 1 by using the same process above - set the desired end time for period 1 in hours then minutes and using the clock key to confirm. After completion of time period 1 the controller will automatically move to time periods 2 & 3 allowing you to set these with the same process. If a time period is not required simply set the start and end time the same which will discard the time period.

#### **7.9. Forced defrosting:**


When the controller is in the main interface display and the heat pump is ON, press and hold the Mode and Down buttons together for 5 seconds to activate or deactivate the "Forced Defrost" function. The symbol  will light up when the "Forced Defrost" is ON.

NOTE – the unit has an automatic defrost cycle. When necessary the unit will automatically reverse it's function to prevent ice/frost from forming on the coil.

#### **7.10. Boost Mode:**

When the controller is in the main interface display and the heat pump in heating mode, press and hold the power and up buttons together for 3 seconds to enable or disable the boost mode. When the boost mode is enabled the heat pump unit and heating element both run. The  will flash initially, then remain on to indicate the element is on. Once the set temperature is reached, the  will revert back to flashing at 1 second intervals to show the heat pump is in boost mode. Turning off the heat pump will exit boost mode.

#### **7.11. Manual sterilization:**

When the controller is in the main interface display and the heat pump is ON, press and hold the power, clock and down buttons together for 5 seconds to enter manual sterilization mode. The symbol  will flash for 2 seconds to indicate Manual Sterilization mode, then will stay lit to indicate the heating element is on. The water will be heated to 61°C, then maintained between 60°C - 61°C for 32 minutes after which the unit will automatically exit sterilization mode.

NOTE – the unit has an automatic sterilization/legionella control cycle whereby the unit will heat the water to a required setpoint one a week between the hours of 1-7am. After this cycle is finished the unit will revert back to it last operating mode

### 7.12. Trouble Shooting:

| Error code | Error Description                           | Possible Causes   |
|------------|---|---|
| <b>E05</b> | Refrigerant system high pressure protection | High pressure switch is broken/connection is loose  |
| <b>E09</b> | Communication failure                       | Signal wire connection is loose or damaged<br>Magnetic field interference<br>PCB is damaged |
| <b>E12</b> | Exhaust temperature too high                | Lack of refrigerant/Fluorine system leak  |
| <b>E15</b> | Tank temperature sensor failure             | Sensor failure/connection is loose  |
| <b>E16</b> | Coil temperature sensor failure             | Sensor failure/connection is loose  |
| <b>E18</b> | Exhaust temperature sensor failure          | Sensor failure/connection is loose  |
| <b>E21</b> | Ambient temperature sensor failure          | Sensor failure/connection is loose  |
| <b>E29</b> | Suction temperature sensor failure          | Sensor failure/connection is loose  |

***If any of the above arise, please contact your installer or supplier***

### 7.13. Status Query Menu:

With the power on and the main interface display showing, press and hold the up or down buttons for 3 seconds to enter the status query menu. Scroll through the values by using the up or down buttons. Push the on/off key to exit the status query interface.

| No.       | Name                          | Value          |
|-----------|-------------------------------|----------------|
| <b>04</b> | EEV open                      | Measured Value |
| <b>05</b> | Coil temp.                    | °C             |
| <b>06</b> | Ambient temp.                 | °C             |
| <b>07</b> | Suction temp.                 | °C             |
| <b>08</b> | Exhaust temp.                 | °C             |
| <b>09</b> | Water Inlet temp.(Water tank) | °C             |

More status queries are available. Contact your supplier for full list if required.

## 8. Commissioning

### Commissioning Check List

#### System Location

- ☐ The unit is installed on a suitable base.
- ☐ Enough room has been allowed for service and maintenance of the water heater.
- ☐ The system has been installed in a location that allows enough ventilation.
- ☐ The location is free from any corrosive materials or chemicals.
- ☐ The location is free from any excessive dust or material that can become airborne.

#### Hydraulic Connections

- ☐ Temperature and pressure relief valve (PTR valve) is properly installed with a discharge pipe plumbed to suitable discernable discharge point.
- ☐ Check that all plumbing connections including piping, valves and fittings are properly installed and free of leaks.
- ☐ The system is completely filled with water and all air is drained from the tank and piping.
- ☐ The tempering valve has been installed per manufacturer's instructions and the output water temperature is in the range required by local authorities.
- ☐ The condensate drain line is installed and plumbed to suitable drain point.
- ☐ All hot water lines are appropriately insulated and protected from UV degradation.

#### Electrical Connections

- ☐ The water heater is connected to a supply that has a voltage between 220 - 240 VAC.
- ☐ All hard wiring complies with all local applicable codes and the requirements of this guide.
- ☐ The water heater and electrical supply are properly grounded.
- ☐ A correctly sized overload protection device has been installed.

## 9. Maintenance

### 9.1. Draining and flushing the system

The system must be completely drained of water before any plumbing work is commenced. This will prevent damage to the storage tank in the event of a vacuum or excessive pressure forming in the storage tank.

The heat pump hot water system should be drained and flushed every five years during a major service of the unit.

- a. Turn off and isolate the power supply to the electrical element.
- b. Turn off the water supply to the water heater.
- c. Release excess pressure from the tank by manually opening the pressure & temperature relief valve.
- d. With the pressure & temperature relief valve open, drain the tank out of the flexible drain pipe

### 9.2. Relief valves

The lever on the relief valves should be operated at least every six months. Failure to do so may result in failure of the tank. If water does not discharge freely from the valves they should be checked and possibly replaced. The relief valves and relief valve drain lines must not be blocked. Some water may discharge during each heating cycle

Every five years, all safety valves should be replaced to ensure continued life and operational safety of the system. In location where the portable water has a Total Dissolved Solids (TDS) of greater than 600 ppm it is recommended to replace all safety valves every 3 years.

### 9.3. Anode replacement

The high quality vitreous enamel lined low carbon steel tanks have a sacrificial anode for long tank life. This anode should be inspected every couple of years and be replaced

when it has worn out. As a minimum it is recommended that the anode be changed every 5 years.

#### **9.4. Condensate discharge pipe**

Check the pipe regularly for cleanliness. Any obstruction may cause poor condensate flow or cause the accumulation of water in the heat pump plastic base.

#### **9.5. Cleaning the evaporator**

The evaporator is integral to the optimum performance of the appliance.

It is recommended to clean the evaporator fins once every year using a soft-haired brush. If any of the fins are bent, carefully realign them using a suitable comb.

### **10.3 Hydraulic circuit**

Check the watertightness of all connections and pipes for signs of any water leaks.

## **WIFI CONNECT** – Connect your Heat Pump via the TUYA SMART HOME APP

1. Make sure the system is powered off (control screen is blank)
2. Download the TUYA SMART HOME APP



3. Turn Controller on and make sure it is unlocked and the WIFI symbol is flashing



4. Click add device
5. Select Larger Home Appliances
6. Select Smart Heat Pump (WIFI)
7. Select your WIFI network & enter your password
8. Confirm the WIFI symbol is flashing fast
9. Wait for the App to connect

**Once connected, the WIFI symbol will remain solid**

## 10. Warranty

**It is recommended that homeowners keep receipts, invoices, warranties and any installation record forms where applicable in a safe place. Proof of purchase/ownership will be required for any warranty claims.**

### 10.1. Warranty Period

Your heat pump is covered by a six year warranty. For the first year the warranty covers parts and labour. The remaining 5 years is a parts only warranty.

### 10.2. Eligibility requirements to make a claim

- The person(s) making the claim must be the product owner or have consent to act on behalf of the owner.
- The product must have its original serial numbers and/ or rating labels where applicable.
- The warranty period begins from the date of installation of the component(s). In the event that proof of installation cannot be provided, the period begins from date of purchase. In the event that this is also not available, the warranty will begin from date of manufacture of the product



### **10.3. General warranty conditions**

10.3.1. This Warranty is for domestic & residential use of the hot water heating system only. Any application with hot water consumption above 700 L/day is considered NON-residential. Domestic is defined per below:

- a. Units installed in any domestic dwelling.
- b. Hot water consumption below 700 Liters per day.

10.3.2. To the extent that a claim falls under the 'Parts Only' Warranty Period, the Warranty covers the repair and/or replacement of such failed component in domestic use free of charge. However, the transport, installation and labor costs of repairing the component or delivering the replacement component and removing and replacing the existing component will be the responsibility of the customer of the existing component.

10.3.3. To the extent that a claim falls under the 'Parts and Labor' Warranty Period, the Warranty covers the repair and/or replacement of such failed component in domestic use and any associated labor costs free of charge. Please note the cost of freight may be charged to the customer.

10.3.4. HSA reserves the right to alter the design, components or construction to its domestic hot water system or custom design. Such alterations shall not constitute a defect in design or construction under this Warranty.

10.3.5. Any claim under this Warranty must include full details of the defect and/or damage to the hot water system or component(s) in domestic use. All claims must be made within one (1) month of the detection of the defect.

10.3.6. To the extent permitted by law, HSA shall not be liable under this Warranty for any consequential loss or damage or any incidental expenses resulting from any breach of this warranty, including but not limited to, claims for damage to buildings, roofs, ceilings, walls, foundations, gardens, personal belonging or household effects, fixtures and fittings, or any other consequential loss, damage or inconvenience, either directly or indirectly due to leakage from the hot water system or component(s) in domestic use or any other matter related to the system or its operation.

10.3.7. The benefits conferred by this Warranty are in addition to all other rights and remedies in respect of the hot water system or component(s) in domestic use, which the purchaser has under the Competition and Consumer Act 2010 and consumer protection legislation of the States and Territories. Nothing in this Warranty has the effect of excluding, restricting or modifying those rights.

10.3.8. Goods presented for repair may be replaced by refurbished goods of same type rather than being repaired. Refurbished parts may be used to repair/replace the goods.

10.3.9. HSA will not accept responsibility for any costs associated with attendance and repair of the appliance by third parties not authorised by HSA and will not settle any invoices arising from this.

#### **10.4. Heat pump warranty conditions**

10.4.1. All heat pump hot water system must be installed by a licensed installer.

10.4.2. Only a licensed professional must install, commission or service the hot water system.

10.4.3. All the hot water system must be installed in accordance with Manufacturer's Installation Instructions and in accordance with local regulations, municipal building codes and current AS/NZS 3000, AS/NZS 3500, AS 3498 and AS/NZS 5601

10.4.4. If the hot water system has not been installed in accordance with Manufacturer's Installation Instructions or installed as to be easily accessible for servicing, a service charge may apply and warranty may be void.

- a. The integration with tank and controller should follow the instructions in the installation manual.
- b. The operational conditions should not exceed from those specified in the installation manual (i.e. -10 to 43 °C).
- c. The storage tank MUST have a 850 kPa PTR valve installed, while the main cold pressure to the hot water system is limited by a 500 kPa PLV.
- d. Electricity supply to the heat pump unit must be accordance with the relevant Australian standards as well as guidelines in the installation manual (i.e. 240V supply and 15A circuit breaker).

This warranty does not cover faults or issues to any components including but not limited to the below:

- accidental damage or damage caused by third parties including damage caused by animals and insect infestations
- corrosion to the unit & casing caused by salty water/air, fire, floods, extreme weather conditions of acts of God.
- damage caused by power surges or faulty electrical supply
- damage caused by connection to anything other than standard water supply, such as springs, bores, dams, rivers etc
- any issues related to excessive water pressure or negative (vacuum) pressure

10.4.5. Water quality must be within limits specified below table.

|                                     |                     |
|-------------------------------------|---------------------|
| Total Dissolved Solids              | < 600 mg/L or ppm   |
| Total Hardness (CaCO <sub>3</sub> ) | < 200 mg/L or ppm   |
| Electrical Conductivity             | 850 µS/cm           |
| Chloride                            | < 300 mg/L or ppm   |
| pH Level                            | Min 6.5 to Max. 8.5 |
| Magnesium                           | < 10 mg/L or ppm    |
| Sodium                              | < 150 mg/L or ppm   |
| Iron                                | < 1mg/L or ppm      |
| Alkalinity (as CaCO <sub>3</sub> )  | < 200 mg/L or ppm   |
| Dissolved (free) CO <sub>2</sub>    | < 25 mg/L or ppm    |

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law.

You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage.

You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.





**HSA - MELBOURNE**

Head Office & Showroom  
11 Fiveways Blvd  
Keysborough VIC 3173  
P: 1300 001 800

**HSA - SYDNEY**

Showroom & Warehouse  
Unit G7, Alexandria Industrial Estate  
35-39 Bourke Road, Alexandria NSW 2015  
P: 02 7209 6235

# Registration Form

DATE OF REGISTRATION

|                      |                      |   |                      |                      |   |                      |                      |
|----------------------|----------------------|---|----------------------|----------------------|---|----------------------|----------------------|
| <input type="text"/> | <input type="text"/> | / | <input type="text"/> | <input type="text"/> | / | <input type="text"/> | <input type="text"/> |
|----------------------|----------------------|---|----------------------|----------------------|---|----------------------|----------------------|

For standard warranty, complete this form and return to:  
Hunt Heating Registration Department, Reply Paid 87857, Keysborough VIC 3175

## PERSONAL INFORMATION

|                   |                      |                      |                        |
|-------------------|----------------------|----------------------|------------------------|
| Prefix :          | <input type="text"/> | First Name :         | <input type="text"/>   |
| Surname :         | <input type="text"/> |                      |                        |
| Telephone :       | <input type="text"/> | Mobile :             | <input type="text"/>   |
| Email Address :   | <input type="text"/> |                      |                        |
| Address :         | <input type="text"/> |                      |                        |
| Suburb :          | <input type="text"/> | State :              | <input type="text"/>   |
| Postcode :        | <input type="text"/> |                      |                        |
| Date of Install : | <input type="text"/> | <input type="text"/> | / <input type="text"/> |
|                   | <input type="text"/> | <input type="text"/> | / <input type="text"/> |
|                   | <input type="text"/> | <input type="text"/> | <input type="text"/>   |

## INSTALLER DETAILS

|                  |                      |                                |                      |
|------------------|----------------------|--------------------------------|----------------------|
| Business Name :  | <input type="text"/> |                                |                      |
| Prefix :         | <input type="text"/> | First Name :                   | <input type="text"/> |
| Surname :        | <input type="text"/> |                                |                      |
| Telephone :      | <input type="text"/> |                                |                      |
| Address :        | <input type="text"/> |                                |                      |
| Suburb :         | <input type="text"/> | State :                        | <input type="text"/> |
| Postcode :       | <input type="text"/> |                                |                      |
| PIC Licence No : | <input type="text"/> | Certificate of Compliance No : | <input type="text"/> |
| Brand :          | <input type="text"/> | Model :                        | <input type="text"/> |
| Serial No :      | <input type="text"/> |                                |                      |

### Important Data Protection Information

If you provide us with information about another person, you confirm that they have appointed you to act for them, to consent to the processing of their personal data including sensitive personal data and that you have informed them of our identity and the purposes (as set out in the Important Data Protection Information displayed when you register your appliance) for which their personal data will be processed.

You are entitled to ask for a copy of the information we hold about you (for which we may charge a small fee) and to have any inaccuracies in your information corrected.  
For quality control and training purposes, we may monitor or record your communication with us.

If your personal details change, if you change your mind about any of your marketing preferences or if you have any queries about how we use your information, Please contact us at 11 Fiveways Boulevard, Keysborough VICTORIA 3173

Hunt Heating will use the personal information that you provide for:

• Customer Service • Administration • To analyse your purchasing preferences • Marketing purposes

We would like to send you information about our own offers and services, as well as those of selected third parties via post, telephone or email.

If you agree to being contacted in any of these ways, please tick the relevant boxes.

Post ☐ Telephone ☐ Email ☐ We may keep your information for a reasonable period for these purposes.

If you do not wish to receive information about our offers or services, please tick this box ☐

If you do not wish to receive information from selected third parties, please tick this box ☐



**HSA - MELBOURNE**

Head Office & Showroom  
11 Fiveways Blvd  
Keysborough VIC 3173  
P: 1300 001 800

**HSA - SYDNEY**

Showroom & Warehouse  
Unit G7, Alexandria Industrial Estate  
35-39 Bourke Road, Alexandria NSW 2015  
P: 02 7209 6235