

Technical Specifications

| | |
|-----------------------------|---------------------------------------|
| Materials | Steel |
| Connections | ½" flow and return. |
| Test pressure | 13 Bar |
| Testing authority | EN442 |
| Maximum operating pressure | 10 Bar |
| Maximum working temperature | 95 °C |
| Packaging | Wrapped in polythene in cardboard box |

Terms & Conditions

All products must be inspected once removed from the packaging and Hunt Heating notified within 28 days of delivery of any scratches, blemishes or other damage. Hunt Heating will then replace the radiator.

Imperfect radiators should therefore not be fitted and Hunt Heating will not accept responsibility for replacement of scratched or damaged radiators once they have been fitted. This includes any consequential loss or cost of fitting.

If Hunt Heating are not notified within 28 days of the date on the signed delivery note then it will be deemed that Hunt Heating have fully complied with its obligations and claims will not be considered.

Failure to comply with any of the above may invalidate any claims.

We recommend that after you check the product on delivery that it is stored in its packaging to prevent damage prior to installation. Hunt Heating cannot accept responsibility for items damaged after delivery.

Guarantees & Liabilities


As we are not the manufacturers of this product we will take all reasonable endeavours to make over to you the benefit of any warranty or guarantee given by the manufacturer, which is usually five years on most of our range. (Copies of specific guarantees for any of our products are available on request).

The guarantees in all cases are subject to the products being installed in accordance with British and or European standards as well as these fitting instructions. The guarantees in all cases are restricted to the free of charge replacement or repair of the failed product only. Our liability will under no circumstances extend beyond the repair or replacement of the product supplied by us. Claims for either labour in replacement or damage to property are not admissible. Any goods that are returned, in the event of a problem, will belong to Hunt Heating.



Poll Range

Fittings Instructions



The Poll is one of our most popular ranges, with high outputs and practical extended towel bars they provide excellent value.

Please read these instructions and terms and conditions carefully prior to installation.

Failure to do so may invalidate the warranty

Hunt Heating
11 Fiveways Boulevard
Keysborough 3173
Victoria




POLL1.1

If you have any questions please contact us on 1300 00 1800
www.huntheat.com.au

If you have any questions please contact us on 1300 00 1800
www.huntheat.com.au

Diagrams of Poll Range



Pipe Centres


| | |
|----------------------------|---------------|
| Pipe centres left to right | width - 30mm |
| Pipe centres from wall | 57mm - 65mm |
| Depth from wall | 132mm - 140mm |

1 Unpack & Inspect

Hunt Heating prides itself on selecting products from manufacturers who exercise tight quality control measures. We only select models with excellent standards of welding and brazing, as well as high quality finishes.

All of our products are well packaged and should reach you in perfect condition. Just in case however, we offer a minimum 5-year no quibble guarantee for all radiators and towel rails.

Please carefully unpack and inspect this radiator and all fittings.



Hunt Heating must be notified of any shortages or damage within 28 days of delivery.

For further information please see terms and conditions on back page.

2 Contents

You should have:

- 1 Radiator
- 4 Wall bracket sleeves
- 1 Airvent

You will need:

- Tape measure
- Electric drill and bits
- Spirit level


3 Mark Bracket Positions

The fixing positions for the two top brackets are measured at 15mm in from either end of the top collector and measured down 90mm (please see diagram opposite).

In order to accurately mark the bottom bracket fixing positions we recommend you mark, fix and level the two top brackets first. Then hang the radiator, ensuring it is vertically level and manually hold the bottom brackets in position while marking.

4 Fix Brackets

Using a suitable drill bit, screws and plugs, fix the brackets sleeves to the wall and level with a spirit level. Please see diagrams.



PLEASE NOTE :

It is essential that all brackets are level to ensure a vertical alignment for connecting the pipework.

5 Hang Radiator & Commission

With the brackets sleeves firmly fixed and level, slot the radiator into the sleeves and firmly fix by tightening the grub screws.

When securing the brackets, we suggest positioning the sleeves in a way which the top bracket's grub screw is facing upwards, and the bottom bracket's grub screw is facing down. This will improve the aesthetics of the radiator and avoid any screws being seen.

Please Note:

In accordance with Part L1 2006 of the Building Regulations and BS7593:1992 code of practice for the treatment of hot water and central heating systems, we strongly recommend flushing the heating system post installation of new radiators and then adding the correct quantity and type of inhibitor for use with your radiator and system to prevent corrosion. Damage caused to systems not protected by a suitable inhibitor will not be covered by manufacturer's guarantee.