


Solazar Natural Convectors

Installation and operating instructions



Index

1 - Introduction	Page 3
2 - General advice	Page 3
3 - Technical specifications	Page 3
4 - Sizes & types available	Page 4
5 - Packaging	Page 4
6 - Maintenance	Page 4
7 - Heat outputs & correction factors	Page 4
8 - Calculating water flow	Page 5
9 - Installation details	Page 5
10 - Problem solving	Page 6
11 - Warranty	Page 6
12 - Dimensions	Page 7

1 - INTRODUCTION

This brochure has been compiled to provide installers with technical information on selecting, installing and operating Solazar natural convectors. Solazar natural convectors are designed as low surface temperature (LST) and low water content, making them ideal for aged care facilities, kindergartens etc. Solazar natural convectors come in a wide range of sizes, providing flexibility for every project. Produced in Melbourne Australia at Hurlcon Heating's manufacturing plant using state of the art manufacturing equipment, the Solazar natural convectors are electrostatically powder coated on our modern powder coating line. Solazar recyclable heat exchangers are manufactured from copper tube with aluminium fins and tested to 13 bar static pressure.

2 - GENERAL ADVICE

1. The convector outputs in this catalogue are quoted with the standard conditions of water temperatures of 90°C flow and 70°C return with an ambient air temperature of 20°C. The convectors can be operated at different water temperatures, with varying heat outputs. Please refer to page 4 for further technical details.
2. Solazar natural convectors are designed to be installed in a hydronic heating system only.
3. Solazar natural convectors can be used indefinitely without changing the water in the system.
4. The pipe work should be pressure tested to eliminate any leaks but **DO NOT** use **MAINS PRESSURE** if the convectors are connected.
5. Use only **OVENTROP** or approved valves on both the flow and return connections. The control valve should be connected on the top manifold/inlet side. The lockshield valve should be connected on the lower manifold/outlet side. NB: The use of thermostatic valves will provide greater comfort and economy.
6. A manual air vent is installed on the heat exchanger to enable venting of the convector.
7. The normal operating pressure is between 1 - 2 Bars.
8. Solazar natural convectors are designed to operate in conjunction with condensing boilers.
9. Maximum water temperature 95°C.

3 - TECHNICAL SPECIFICATIONS

All Hurlcon Solazar natural convectors are manufactured to the following specifications:

- | | |
|---------------------|--|
| • Steel casing | 1.15mm Galfan |
| • Wall Brackets | 0.75mm Galfan |
| • Heat Exchanger | 16mm Copper with 0.2mm aluminium fins |
| • Test pressure | 13 BAR minimum |
| • Working pressure | 10 BAR maximum |
| • Connections | 1/2" BSP |
| • Powdercoat Finish | Horizon White 901-51608 Dulux Surreal Effect
Scylla Ripples |
| • Air bleed | 1/8" BSP |

4 - SIZES & TYPES AVAILABLE

Solazar convectors range of lengths: 600, 800, 1000, 1200, 1400, 1600, 1800, 2000 and 2400mm.

Heights: 300, 450, 600, 750 and 900mm.

Depth: 124mm (4 Tube) and 184mm (6 Tube).

NOTE: All Hurlcon Solazars are manufactured to order, lead times are 4-6 weeks depending on quantities. This should be checked with your nearest Hurlcon sales office prior to scheduling of installation.

5 – PACKAGING

1. In order to protect the Solazar convector and avoid external damage, all Solazars convectors are packed with bubble wrap packaging.
2. The Solazars are labelled with job and part number.

6 - MAINTENANCE

1. Any dust build up in the heat exchanger can be easily removed using a vacuum cleaner, the front cover can be removed to provide easy access.
2. The casing should only be cleaned using a soft cloth and warm soapy water, please do not use corrosive or abrasive agents to clean your convector.

7 - HEAT OUTPUTS AND CORRECTION FACTORS

How to select a Solazar natural convector:

Heat outputs vary according to the difference between the room air temperature and the average of the flow and return water temperatures (mean water temperature). The data supplied is based on 90/70°C water temperature and a room temperature of 20°C .

Wall mounted outputs kW's

HEIGHT (H mm)	TUBES (T)	LENGTH (L mm)								
		600	800	1000	1200	1400	1600	1800	2000	2400
300	4T	0.73	1.04	1.35	1.67	1.98	2.30	2.61	2.93	3.56
	6T	1.04	1.50	1.98	2.40	2.90	3.36	3.82	4.28	5.20
450	4T	0.81	1.17	1.52	1.88	2.23	2.59	2.94	3.30	4.00
	6T	1.17	1.68	2.19	2.70	3.20	3.72	4.23	4.74	5.75
600	4T	0.94	1.35	1.75	2.16	2.56	2.97	3.38	3.79	4.60
	6T	1.34	1.93	2.51	3.10	3.68	4.27	4.85	5.44	6.60
750	4T	0.98	1.40	1.83	2.26	2.68	3.11	3.54	3.96	4.82
	6T	1.40	2.01	2.63	3.24	3.85	4.46	5.07	5.68	6.91
900	4T	1.05	1.50	1.95	2.41	2.86	3.32	3.77	4.23	5.14
	6T	1.50	2.15	2.80	3.46	4.11	4.76	5.42	6.07	7.38

Correction Factors

M.E.D.	30°C	40°C	50°C	55°C	65°C	70°C
Factor	0.38	0.50	0.77	0.90	1.11	1.22

For temperatures other than 60°C, use the table above for correct emissions. To calculate the obtain Mean Effective Temperature Difference (M.E.D.) use the following equation: $M.E.D. = \text{Flow} + \text{Return water temp.} / 2 - \text{Room Temp.}$

8 - CALCULATING WATER FLOW

To ascertain water flow requirement the following information must be calculated:

- Selected output
- Temperature difference between Flow and Return (ΔT)

Calculate flow rates in l/s using the following formula:

$$\text{Flow in l/s} = \frac{\text{output kW}}{\Delta T \times 4.18}$$

Example:

Required output of 2.0 kW

Boiler capacity - flow 80°C return 70°C thus $\Delta T = 10$

The calculation is:

$$\text{Required Flow} = \frac{2.0}{10 \times 4.18} = 0.048 \text{ l/s}$$

9 - INSTALLATION DETAILS

1. The Solazar heat exchanger can be installed as either a left or right hand installation, by simply rotating the heat exchanger to allow pipe connections to be made on either end of the casing.
2. **Please Note:** *Do not overtighten pipe fittings, recommended 15 N-m torque maximum.*
3. The Solazar must be installed between 100 and 200mm from floor level to bottom of the convector.
4. Ensure clear air flow through the Solazar, no obstructions such as shelves should be immediately above.
5. Dimensions for the outer casing, along with measurements for fixing points on the wall mounting brackets are on the drawings on Page 7.
6. Pipework can exit the wall behind the casing if you bring pipework down through the wall from above.
7. Fix the wall mounting brackets vertically to the wall, ensure that the top of the brackets are level, refer Page 7.
8. Slide the heat exchanger into the brackets.
9. When fixing brackets, please take into consideration the limited adjustment as per slots in the base of the front cover.
10. Fit the outer casing top and side assembly.
11. Fit the front panel after the pipework connections have been completed and the thermostatic head or manual handle has been fitted. The front panel can be easily removed when necessary for system commissioning.

10 - PROBLEM SOLVING

1. Solazar convectors require the correct hot water flow rate to operate correctly.
2. Solazar convectors must be free of air to operate correctly.
3. The total heating system water quality must be maintained and free of air at all times for the convectors to operate correctly.

11 - WARRANTY

Solazar natural convectors are warranted for 10 years against defects in material or workmanship. Warranty includes rework or replacement of the convector (parts only).

This warranty **DOES NOT COVER** any labour charges, travel time expenses, or any consequential losses or damage.

The products must be installed and used according to accepted plumbing practices such as BS5449. Failure to do so will void the warranty.



The below items must also be followed or else the warranty may be voided:

1. Solazar Natural Convectors must only be used for the purpose for which they are intended.
2. Please ensure that the connection elements are free of any dirt and burr after the installation.
3. After installation the system must be properly flushed.
4. When filling the convectors for the first time, heating system controls should be closed and the system should be set to the correct pressure.
5. Do not overtighten the airvents or valves, or the connection threads could be damaged.
6. After the installation, the system should be tested by qualified personnel only.
7. Do not use the convectors in humid environment (swimming pool, sauna bath, green house).
8. Please take precautions against the risk of freezing.
9. Avoid dropping or flexing (bending) the convectors when carrying or transporting.
10. Please do not use corrosive or abrasive agents to clean your convector.
11. Placing more than 10 kgs weight onto the convector may result in brackets coming out of the wall.
12. This warranty shall not apply to any convectors that have been subject to accident, negligence, alteration, abuse or misuse.


12 - DIMENSIONS

BRACKET LOCATIONS AND DIMENSIONAL

DRAWINGS WALL MOUNT 4 & 6 TUBE



6 Tube heat exchanger



DETAIL A

SCALE 2 : 5

MODEL	G
4 TUBE	58.15
6 TUBE	86.65

HEIGHT	E	F
300	205	-
450	185	185
600	250	250
750	310	310
900	375	375

LENGTH	A	B	C	D
600	110	110	-	-
800	150	150	-	-
1000	185	185	-	-
1200	225	225	600	-
1400	260	260	700	-
1600	295	295	800	-
1800	330	330	900	-
2000	370	370	700	700
2400	445	445	900	900



installation and operating instructions

Hurlcon Hydronic Heating
111 Indian Drive
Keysborough Victoria, Australia, 3173
Ph: +613 9554 2275 Fax: +613 9554 2272
email: enquiries@hurlconheating.com.au

www.hurlconheating.com.au



A division of AstralPool Australia Pty Ltd
ABN 97 007 284 504

V3140617

Hurlcon Hydronic Heating reserves the right to make modifications and change specifications without notice E & OE